

Omnixie Tube Clock Series Quick Start Guide



The Light Never Fades
www.omnixie.com

To get started setting up WiFi, power on the clock, open the WiFi settings on your smartphone, tap the signal named "NCHxxxxxx", and follow the prompt in the pop-up windows.

The clock can be controlled either by 1) the web browser on a phone/computer once WiFi is connected, or 2) the remote control.

Basic Operations	Power On/Off	WiFi	Status Indicator (under the mesh behind the first tube from the left)	
	Press the Power button on the remote.		Green LED	Internet Online, NTP Server Online
	Display: Time, Date, Alarms	Yellow LED	Internet Online, NTP Server Offline	System Menu
	Time After power on Date DATE(once Gregorian; twice: lunar) 4 Alarms ALARM(1-4 times); FUNC to enable or disable.	Red LED	No Internet, NTP Server Offline	
	Settings: Time, Date, Alarms	Navigating in the System Menu FUNC > ←/→ > SET > ←/→ > OK/CANCEL		
	Set Time SET > ←/→ > 0-9 > OK Set Date DATE > SET > ←/→ > 0-9 > OK Set Alarms ALARM > SET > ←/→ > 0-9 > OK	Menu Items		
	Tube Brightness	Set 12/24 Hour Mode	01	24H (Default), 12H
	Brightness Press LIGHT repeatedly 00(auto), 1(dark)-8(bright)	Set Date Format	02	1(YMMDD; Default), 2(YDDMM), 3(DMMYY), 4(MMDDYY)
	Current Time Speaking	Set Interval of Time Display	03	00-60sec (Default: 00)
	Press any digit or OK when displaying time	Set Interval of Date Display	04	00-60sec (Default: 00)
Speaker Volume	Show/Hide Leading Zero	05	1(show; Default), 2(hide)	
Press ← or → to adjust volume. 0(mute) - 1 ... 8 (loudest)	Set Switching Effects	06	1(jump), 2(fade in/out), 3(cross-fading; Default), 4(slot machine)	
	Set Switching Speed	07	1(fastest)-10(slowest); Default: 07	
	Set Colon Animation Effects	08	1(fade in/out; Default), 2(blinking), 3(always on), 4(always, off)	
	Set Alarm Sound Tone	09	01-12 (Default: 01)	
	Set Alarm Volume	10	1(min)-8(max); Default: 7	
	Set Speaking Clock Language	11	1(Chinese; Default), 2(English), 3(Japanese), 4(German)	
	Set Interval of Talking Clock	12	0(disabled), 1, 2, 3, 5, 10, 15, 20, 30, 60min (Default: 60)	
	Set Backlight Effects	13	1(always off), 2(fade in/out), 3(always on; Default)	
	Set Backlight Color	14	01-15 (Default: 09)	
	Set Interval of Cathode Poisoning Prevention	15	0(disabled), 1, 2, 3, 5, 10, 15, 20, 30, 60min (Default: 10)	
	Set Duration of Cathode Poisoning Prevention	16	5-30sec (Default: 5)	
	Show Firmware Version	17	v 1.x.x	



User Manual